


Frigo Granita MT UL AF Frozen Drink Machine

Power Switch Settings.



Switch “A”: Powers Unit **ON** and **OFF**
Power switch “O” position is **OFF**
Power switch “1” position is **ON**

Switch “B”: Controls the Mixer and refrigeration mode.
Switch “O”: **OFF**
Switch “1”: Mixer and refrigeration **ON** for **SOFT DRINK** mode.
Switch “11” Mixer and refrigeration **ON** for **SLUSH** mode.

Switch “E”: Light switch
Switch “O”: **ON**
Switch “1” **OFF**

Thermostat “D” works in **SOFT DRINK** mode only
Turn Clockwise: To decrease temperature
Turn Counterclockwise: To decrease temperature

Safety pressure switch warning light “C” ON - Insufficient ventilation.

To operate the unit:

1. Set the power switch to “1” position
2. Set the mixer/refrigeration switches as follows:
 - to the “1” position to get soft drink.
 - to the “11” position to get slush drink.
3. Each bowl has individual switch “B” settings.